

**Congratulations on your purchase of the Exposure 2010 CD Player. This precision electronic component has been designed to offer the finest possible musical performance. Please read this Owner's Manual carefully. Proper care and understanding in the installation and operation of this High Fidelity unit will ensure optimal performance and satisfaction from your purchase. Please do not hesitate to contact your retailer or local distributor if there are any issues which have not been covered in this manual.**

## Introduction

An Exposure 2010 CD Player may take up to 48 hours to "run-in" before reaching its optimal performance. As each subsequent "run-in" will then take about 30 minutes, and since the 2010 CD Player consumes very little power when left on standby, it may safely be left on even when not in use.

## Installation and connection

Before installing this unit, please ensure that:

- All associated system components are operating correctly
- Cables are serviceable and of good quality\*
- The surface is level and sturdy
- There is ample access to the rear of the unit

1. Connect the supplied mains cable to the IEC mains input socket.
2. Connect to the mains outlet on the wall.
3. Ensure that all input and output connections are made BEFORE switching on this unit.

## Outputs

The Exposure 2010 CD Player is fitted with *both* analogue and digital audio outputs.

### Analogue output

Connect RCA phono sockets to appropriate line input, making sure right and left channels are properly connected. (*Right channel is marked in red*)

### Digital output

Connect the digital outputs either to:

1. An external digital to analogue converter, or
2. To a digital device such as a CDR machine or minidisc recorder.

Both TOSLINK and coaxial BNC sockets are provided for these applications.

\*Do not substitute the supplied 2010 series mains cable for an alternative. Doing so may damage the unit and void the warranty.

## Operation

Before switching on your Exposure 2010 CD Player for the first time, ensure that:

1. All connections are correct and secure
2. The amplifier volume control is set to minimum
3. The mains plug is connected to the mains wall socket.

Switch the unit on by depressing the power switch on the front panel. The LED power indicator will light up and the display will illuminate.

### **Exposure 2010 CD Player function controls:**

<b>Open</b>	Opens and closes the CD loading drawer
<b>Stop</b>	Stops disc playback
<b>Play/Pause</b>	Starts disc playback. Pressing Play/Pause while a disc is playing will pause playback. Pressing Play/Pause again will resume playback.
<b>&lt;&lt;</b>	Selects the previous track in sequence.
<b>&gt;&gt;</b>	Selects the next track in sequence.
<b>Display</b>	Pressing Display On/Off once will turn the display off. Pressing Display On/Off again will turn the display back on. NB. Switching the display off <i>may</i> provide a worthwhile <b>sonic</b> improvement in the unit's performance.

### **Remote Control**

Your Exposure 2010 CD Player is supplied with the **HS-1 remote control handset** as standard. This unique unit is capable of operating *both* the 2010 CD Player (the buttons on the upper portion of the unit), as well as the Exposure 2010 Integrated Amplifier (the buttons on the lower portion of the unit). The function of each button on the HS-1 remote control unit duplicates the function of those located on the fascia of the 2010 CD Player. Also included is a button to operate the disc repeat function.

The batteries required to operate this unit are also supplied.

*The Exposure 2010 CD Player may also be remotely operated using the **Exposure System Remote Control Unit** (sold separately).*

## Safety

As with any mains powered electrical product, incorrect installation or inappropriate use of the Exposure 2010 CD player may result in injury due to electrical shock.

- Ensure that the voltage rating on the rear panel of this unit matches that of your local mains supply.\*
- Ensure that the mains cable and plug supplied with this unit is also correct.

(Contact your dealer immediately if this is not the case)

- This unit is protected by a mains fuse which is accessible from the rear panel.
- Fuse replacement specifications:

220/240V units	T1A fuse
110/120V units	T2A fuse
- The 2010 CD player MUST be earthed.
- Protect unit against all forms of liquid. Never expose unit to dripping or splashing, or place objects filled with water, such as vases, on the device.
- Unplug unit from mains when not in use for prolonged periods.
- Do not open this unit – there are NO user serviceable parts inside.
- Reduce the amplifier volume control to minimum before turning this unit on or off.
- Ensure that this unit is switched off when connecting or disconnecting interconnect cables.

\*Contact Exposure Electronics for advice on moving your equipment to another country or territory.

## Caution

For a long and trouble free life of your Exposure 2010 CD Player, please ensure the following:

- Do not apply labels or stickers to CDs
- Do not write on CDs
- Do not use abrasive or solvent based cleaning fluids on the surface of CDs
- Do not remove the cover of the CD Player or dismantle the case
- Do not operate the CD Player in a damp environment or allow liquids to enter the unit
- Do not attempt to bypass the mains fuse or replace the fuse with one of a different specification
- Do not place the CD Player in a position which restricts cooling airflow around it's case
- Do not use abrasive or solvent based cleaning fluids on the CD Player's case

Failure to observe these precautionary measures may void your warranty.

## Technical Specifications

Output Level:	2V RMS
Frequency Response:	20Hz – 20 kHz $\pm$ 0.03dB
Total Harmonic Distortion:	<0.008%, 20Hz – 20 kHz, 0dBFs
Signal to Noise Ratio:	>100dB, A weighted
Digital Outputs:	SP/DIF, Coaxial and "TOSLINK" Optical
Mains Supply:	110/120V or 220/240V, 50/60Hz (factory set)
Power Consumption:	25 Watts
Dimensions (H x W x D):	90mm x 440mm x 300mm
Gross Weight (Packed):	7.0kg
Nett Weight (unpacked):	6.0kg

## Exposure Warranty Policy

The Exposure warranty entitles you to have this unit repaired, free of charge, during the first three (3) years from the date of purchase, provided that it was purchased from an authorised Exposure dealer in your country of residence.

The agent can accept no responsibility for defects arising from accident, misuse, abuse, wear and tear, neglect or through unauthorised adjustment and/or repair or replacement of any components, nor can they accept responsibility for damage or loss occurring during transit to or from the person making a claim under the warranty.

All equipment warranties are valid only if registered with the authorised agent in your country of residence and issued with a recognised warranty card.

The Exposure warranty covers:

**Parts and labour costs for three (3) years from the date of purchase.** Please retain your original receipt as proof of purchase and purchase date. The guarantee is extended only to the original purchaser and is not transferable.

When making claims under this guarantee:

1. The equipment should be suitably packed and returned to the dealer from whom it was purchased, or should this not be possible, directly to the local distributor, together with proof of purchase or a copy of the dated sales receipt.
2. If necessary the unit should be sent carriage pre-paid by a reputable carrier – NOT by post.
3. No responsibility can be accepted for the unit whilst in transit to the dealer or agent, and customers are therefore advised to insure the unit against loss or damage whilst in transit.
4. The warranty card MUST be produced when making claims against this guarantee.
5. Any tampering or alterations made to the warranty card or to the serial number on the equipment will invalidate the warranty.
6. The dealer or the agent shall notify the customer when the repairs have been completed. The customer must claim the goods within fourteen days from the date of notice, failing which; the Company reserves the right to impose storage charges.
7. The Company reserves the right to dispose of the equipment after 90 days from the date of notice in a manner that it sees fit and without compensation to the customer.